

Application Guidelines for Digital Transfers

HEAT PRESS:

1. Preheat garment to remove excess moisture
2. Align transfer and cover with parchment or butcher paper
3. Temperature: 325 degrees
4. Time: 10-25 seconds
5. Pressure: 1-2level
6. Allow Transfer to COOL COMPLETELY before removing clear film
7. Lay Parchment Paper over design and repress for an additional 10 seconds to cure into shirt
8. Wait 24 hours before washing or stretching



IRON ON:

1. Temperature: Heat up your iron to Linen Or Cotton Settings (at least 160 deg No Steam)
2. Iron the desired area to eliminatie any moisture
3. Time: 10-25 seconds
4. Pressure: Heavy
5. Allow Transfer to COOL COMPLETELY before removing clear film
6. Lay Parchment Paper over design and repress for an additional 10 seconds to cure into shirt
7. Wait 24 hours before washing or stretching



Follow us on
Instagram

@eprintall